

Pro-Tect WB

WATER BASED CONCRETE SEAL

Pro-Tect WB is a proprietary blend of acrylic polymers specifically designed to provide a higher level of durability than conventional water-based sealers. It's formulated for use on sealed or unsealed concrete. It can be used on both interior and exterior concrete. Pro-Tect WB is resistant to water and many chemicals and oils. It is designed for easy application. No special acid etching or other preparation is necessary. Simply deep clean the floor and apply Pro-Tect WB for a great looking, durable floor.



DIRECTIONS

Pro-Tect WB has been specially formulated to provide an acrylic matrix that offers incredible strength and durability. The floor surface should be aggressively cleaned and dry before applying Pro-Tect WB. Clean the floor surface with a high pH, butyl cleaner and brushes or aggressive floor pads.

After the floor is cleaned, rinse with clear water and let the floor dry completely before applying the product. After the floor is clean and dry, apply the first coat of Pro-Tect WB with a rayon finish mop, flat finish mop or a T-bar type of applicator. If a finish mop or flat mop is used, be sure to overlap the outside lines before the seal dries to prevent visible lines.

After the first coat is dry, (approx. 1-2 hours) apply the second coat in the same manner as the first. A third coat is usually not necessary but can be applied if a higher gloss is desired.

Routine maintenance should include dust mopping to remove all surface dust and debris. Regular cleaning should be performed with an autoscrubber or mopping with a neutral cleaner.

PHYSICAL PROPERTIES

APPEARANCE: Milky White Liquid

SPECIFIC GRAVITY: 1.03

ODOR: Characteristic

pH (Conc.): 7-8

FLASH POINT: >200°F

PACKAGING

This product is available in 2.5 gallon pails

PRECAUTIONARY STATEMENT

Prevention: Wash hands and exposed skin thoroughly after handling. Wear eye protection/face protection.

Response: If skin irritation occurs: Get medical advice/attention. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention.